




Oco HD
Setup Guide

Hi, I'm Oco HD!

I'm very easy to install.
However, if you have any
questions, don't hesitate to
contact our 24/7 support team
at support@getoco.com,
or call us at 1-888-683-8950
(English speakers only).



Description of the Device



1. Speaker

2. Lens

3. IR LED


4. Status indicator

5. Microphone

6. USB input

7. Reset button

8. MicroSD memory card slot



Before You Get Started

Please make sure you have everything you need to set up your Oco HD:



Oco HD Camera



USB cable ×1



Power adapter



2 screws and 2 drywall anchors



Mounting base



Setup guide

- * The items illustrated may differ from those in the package.
- ** The power cable does not provide data transfer.
- *** Smartphone is not provided.

Download the App

Download the Ivideon mobile App from the Apple App Store or Google Play Store. Then, launch the app and create your account.



Set Up Oco HD

You can set up the camera in two ways:

- 1. Place it on a flat surface.**
- 2. Mount it on a wall** using the magnet stand as a wall mount.

Connect the camera to the power outlet using the enclosed power adapter and Micro-USB cable .

Add Oco HD Camera to Your Account

1. Connect your smartphone or tablet to the same Wi-Fi network that you are going to use with the Oco HD camera.
2. Click the **Add a new camera** or **+** icon in the Ivideon mobile App to add the camera, and follow the instructions.

Connecting the camera can take up to 1 minute.

The status light will glow a steady green ● when the configuration procedure is successfully completed.



Note: To make the camera work in another Wi-Fi network, it is necessary to reset the settings, and repeat the setup procedure. To reset the settings, hold down the RESET button on the back panel of the camera for 3 seconds until the camera beeps.

Add Cloud Recording Service

Sometimes you need to add more people to your account, or you need to store data for a longer period. That is where our extended plans come in handy. You can activate the extended cloud recording and the enhanced features (such as additional users per account) by choosing one of the price plans. Or you can continue with our basic free plan.

Grant Access to Other Users

You can use this feature if you wish to grant access to your Oco HD camera to other users. In your Ivideon app, choose **Camera** and then tap to **Camera settings** → **Grant access**

Set Up Hybrid Storage

Our cameras give you the flexibility to store footage in the Cloud and locally. With Oco HD, you can use a microSD card as a local storage. *Please note that the events snapshots are stored in the Cloud even if you use microSD card and basic free plan.*

Insert the microSD card into the Oco HD camera. Reboot the camera by turning the power off and then on again. The microSD card will be automatically formatted for use in the Oco HD camera. The Timeline with archive recordings should appear on the camera view screen in the Ivideon app.



Note: To store the video archive on a microSD card, we recommend you use a microSD card with Speed Class 6 or higher. Oco HD supports microSD cards up to 128Gb.

Adjust Notifications Settings

You can choose which types of notifications you would like to receive – e-mail, push, or both. In your Ivideon app, choose

Camera and tap to

Camera settings → Notifications (Settings)

Adjust the Sensitivity of the Motion/Sound Sensors

Oco HD uses an intelligent self-learning algorithm to avoid false notifications.

But if you'd like to adjust sensitivity of the sensors manually, open your Ivideon app, choose Camera and tap

Camera settings → Motion/sound

Integrate Other Smart Devices via IFTTT

With IFTTT, your Oco HD camera can communicate with other smart devices or function according to your geolocation, weather, or Moon phase. You can enhance the capabilities of the Oco HD by using ready recipes or by creating your own at ifttt.com/oco_camera

